
DESCRIPTION:SOCCER GOAL
PLEASE READ THESE
INSTRUCTIONS CAREFULLY
BEFORE USE

SOCCER GOAL



SIZE:2470*1830*1200mm
SIZE:3050*1830*1200mm
SIZE:3650*1830*1200mm

PART LIST

Ⓐ 2PCS	Ⓑ 2PCS	Ⓒ 2PCS	Ⓓ 6PCS	Ⓔ 4PCS	① 4PCS
JOINT	JOINT	JOINT	JOINT	JOINT	ø68x1132
② 2PCS	③ 2PCS	④ 2PCS	⑤ 1PC	⑥ 1PC	⑦ 1PC
ø68x815	ø68x815	ø68x1050	ø40x735	ø40x710	ø40x735
⑧ 1PC	⑨ 2PCS	⑩ 30PCS	⑪ 10PCS	⑫ 2PCS	⑬ 2PCS
ø40x710	ø40x645	CLIP	EARTH NAIL	ø68x530	ø68x1132
⑭ 1PC	⑮ 1PC	⑯ 1PC	1PC		
NET(240cm green mark)	NET(305cm blue mark)	NET(365cm red mark)	HAND BAG		


OWNER'S MANUAL

IMPORTANT!

Use this porducts on open areas. Dont play in the street.Use it under the supervision of an adult.For children over 10 years old.


ASSEMBLY SIZE: 2470*1830*1200mm

A



A.Assemble the frame according to the serial number marked.


B



B.Assemble the rear support frame.


ASSEMBLY SIZE: 3050*1830*1200mm

A



A.Assemble the frame according to the serial number marked.


B



B.Assemble the rear support frame.


ASSEMBLY SIZE: 3650*1830*1200mm

A




A.Assemble the frame according to the serial number marked.

B



B.Assemble the rear support frame.

C



C.To attach net to goal, first please find two colored marks on the top of the goal net, in this direction, attach it on the top goal post, then tie the rope and the post with push mount clip#10 and fasten it.
Please fixed the goal with the earth nail#11.

